



Notes:

1. Silt fence shall be installed before any earth removal or excavation takes place.
2. Set posts maximum 8 feet on center and excavate 6"x6" trench upslope along the line of posts.
3. Attach filter fabric to posts and extend it into trench.
4. Backfill and compact excavated soil.

Digital Standard Drawings and other maps are available on the City website: http://www.ci.missoula.mt.us/publicworks/gis_maps.htm



Silt Fence Installation

Approved By City Engineer

R. Steven King
R. Steven King

Adopted: 01/01/2005

Revised:

STD - 604